


Composer

Media Edition

User Guide



Composer User Guide - Media Edition

This guide is also available in the Composer software as on-line help. To access the online version, start Composer and then choose Contents from the Help menu.

Disclaimer

Control4 ® makes no representations or warranties with respect to this publication, and specifically disclaims any expressed or implied warranties of merchantability or fitness for any particular purpose. Control4 reserves the right to make changes to any and all parts of this publication at any time, without any obligation to notify any person or entity of such changes.

Trademarks

Control4 and the Control4 logo are registered trademarks of Control4 Corporation. Other product and company names mentioned in this document may be the trademarks or registered trademarks of their respective owners.

Copyright

Copyright © 2004-2008 Control4. All rights reserved. No part of this publication may be reproduced, photocopied, stored on a retrieval system, or transmitted without the written consent of the publisher.

Copyright © 2005-2008 All Media Guide, LLC provides media recognition technology that provides cover art and related text that enriches the Control4 user interfaces.

Copyright © 2005-2008 Skybound Software. This program includes software developed by Skybound Software (<http://www.skybound.ca>).

Legal Notice

Fraunhofer IIS and Thomson. MPEG Layer-3 audio coding technology licensed from Fraunhofer IIS and Thomson. Supply of this product does not convey a license nor imply any right to distribute content created with this product in revenue-generating broadcast systems (terrestrial, satellite, cable, and /or other distribution channels), streaming applications (via Internet, intranets, and/or other networks), other content distribution systems (pay-audio or audio-on-demand applications, and the like) or on physical media (compact discs, digital versatile discs, semiconductor chips, hard drives, memory cards, and the like). An independent license for such use is required. For details, please visit <http://mp3licensing.com>.

Patent Pending.

Control4 Corporation
11734 S. Election Road
Salt Lake City, UT 84020
USA

<http://www.control4.com>

Control4 Composer User Guide - Media Edition
Part Number: 200-00080, Release 1.6, June 2008

Contents

Chapter 1	Get Started	1
	Software and Network Requirements	2
	Install Composer Media Edition Software.....	3
	Start Composer Media Edition Software	4
Chapter 2	Introduction to Composer Media Edition Software	7
	Composer Media Edition Startup	8
	Directors Dialog.....	9
	Media View.....	10
	Menu Bar.....	11
	File Menu	12
	Media Menu	13
	Help Menu	14
Chapter 3	Set up Media and Playlists	15
	Set up Media on a Controller	15
	Set up Media on DISC Changer	17
	Autoscan Media Within Composer	22
	Set up Media for Broadcast Television Channels.....	23
	Set up Media for Broadcast Stations	25
	Use External Storage Devices	26
	Add an Audio or Audio/Video Switch to Control4 System	28
	Create Playlist	29
	Refresh Navigators	31
	Edit Media Information within Composer	31
Chapter 4	Other Composer Tasks	37
	Clear Media List	37
	Connect to Director on Local Network.....	38
	Exit Composer.....	39
	Export Media List	39
	Import Media List	39
	Search Topic.....	40
	Update Composer Media Edition from Help Menu	40

Update Composer Media Edition from Windows Start Menu	40
Update Composer Media Edition by Running Installation	40
View Index	41

Control4® Composer Media Edition is the software you use to add and scan media and create playlists on the Control4 system. It is a Windows XP-based PC program that has a drag-and-drop interface.

The center of the Control4 system is the Media Controller or other Control4 controller hardware, such as Home Theater Controller.

The controller hardware communicates with Control4 and third-party products to enable home automation and interaction of individual devices.



NOTE: When the term “controller hardware” is referenced in this documentation, it refers to any Control4 product that contains the Director component, such as Media Controller or Home Theater Controller.

Topics covered in this chapter:

- ▶ “Software and Network Requirements”
- ▶ “Install Composer Media Edition Software” on page 3
- ▶ “Start Composer Media Edition Software” on page 4

Software and Network Requirements

This product requires that your system is functioning correctly before attempting to use the software. Please see your authorized Control4 dealer if this product does not work as documented because it indicates that the Control4 system is not set up properly.

Software and network requirements for using Composer Media Edition:

- ▶ Control4 controller hardware (such as Media Controller)
- ▶ PC Software and Hardware
 - Composer Media Edition (launches Microsoft .NET 1.1 web install)
 - Microsoft Windows XP and Service Pack 2 (Home or Professional)
 - 500 Mhz processor or higher
 - 256 MB RAM
 - 80 MB Hard Disk space
 - Video card and monitor supporting resolution of 1024x768 or higher
 - Keyboard
 - Mouse
- ▶ TCP/IP-based home network (DSL/Cable Modem, Control4 Secure Gateway, router, or switch) to connect PC to controller hardware
- ▶ Internet Connection (broadband required for retrieving cover art and media information)
- ▶ Windows Media Player 9
- ▶ Registration at my.Control4.com is required

Install Composer Media Edition Software

To install Composer Media Edition software:

1. Launch the Composer Media Edition installation and follow the on-screen instructions. You might be asked for a registration key.



2. When prompted to update, follow the on-screen instructions to update to the latest version of Composer Media Edition.

The software version and the drivers might have been updated since the CD or Web download was created. It is recommended that you always choose to update.



TIP: You have three options for updating Composer, including:

- “Update Composer Media Edition from Help Menu” on page 40
- “Update Composer Media Edition from Windows Start Menu” on page 40
- “Update Composer Media Edition by Running Installation” on page 40

Start Composer Media Edition Software

When you start Composer Media Edition software, you must connect to Director on your home network.

To start Composer Media Edition Software:

1. From the desktop, double-click the **Composer** icon.



2. At the Composer startup screen, choose **Director on Local Network**.




The **Virtual Director** and **Remote Director** shown on the Startup screen are not available with the Composer Media Edition.

3. From the Director dialog that appears, choose the Director's address of the physical hardware (such as Media Controller) you are setting up.




TIP: If the Director's address does not appear immediately, click the **Refresh** button. If it still does not appear, contact your authorized Control4 dealer.

4. Click **Connect**.




Composer is opened to the main Composer Media Edition interface



Chapter 4 Introduction to Composer Media Edition Software

The *Composer Media Edition* interface allows you to add and scan media to your controller hardware, such as Media Controller.



You can also create playlists of MP3 files saved on the controller hardware's hard drive in the Media Database.

Adding or scanning media allows you to view and select the stored/ broadcast media and playlists from the Navigator devices, including Wireless Touch Screen, On-screen, Mini Touch Screen, and System Remote Control.

Topics covered in this chapter:

- ▶ "Composer Media Edition Startup"
- ▶ "Directors Dialog" on page 9
- ▶ "Media View" on page 10
- ▶ "Menu Bar" on page 11

Composer Media Edition Startup



From the Composer Media Edition Startup Screen, you can connect to controller hardware locally (center option).


The Composer Media Edition does not provide the Virtual (left option) or Remote Director (right option) options.

-
- Startup Screen** ▶ **Director on Local Network.** Allows you to manage media while connected to a Director on your home network. Launches the Directors dialog. For more information, see “Directors Dialog” on page 9.
- ▶ **Exit Composer.** Allows you to exit Composer and return to the desktop. When you exit, Composer prompts you to back up your project to your PC hard drive.

Related Tasks:

- ▶ “Connect to Director on Local Network” on page 38
- ▶ “Exit Composer” on page 39
-

Directors Dialog



This Directors dialog appears when you click the **Connect to a Local Director** from the Startup screen.

Connecting to a Director on the home network allows you to set up your media on your controller hardware so it is viewable on the Navigator devices, such as Wireless Touch Screen, On-screen, and Mini Touch Screen.

Each Director has an associated address.


Directors dialog

- ▶ **Connect.** Allows you to connect to the Director that resides on controller hardware on the home network.
- ▶ **Cancel.** Cancels and closes the Director dialog box.
- ▶ **Add.** Launches a dialog that allows you to add the Director's address of the controller hardware you are trying to connect.
- ▶ **Refresh.** Allows you to update the Director list to display recently added Directors.

Related Tasks:

- ▶ "Connect to Director on Local Network" on page 38
-

Media View



The **Media** view allows you to add to the system your media selections, including stored music and media collections or broadcasts channels and stations.

Adding media in Composer Media Edition allows you to view and select the stored or broadcast media from the Navigator devices, including Wireless Touch Screen, On-screen, Mini Touch Screen, and System Remote Control.

Media View

(left-side selections change right-side view)

There are two types of media in the system:

- ▶ **Stored Media.** Includes the possible media types:
 - ▶ **CD.** Allows you to store CD selections by viewing jacket art, album, artist, and genre type (such as rock or country).
 - ▶ **DVD or Disc Changer.** Allows you to store DVD and CD selections by viewing jacket art, title, info, results, media, and disc list.
 - ▶ **MP3 on Digital Audio Player.** Allows you to store MP3 — HDD Music selections by viewing jacket art, album, artist, and genre type (such as rock or country).
- ▶ **Broadcast Media. Includes the possible media types:**
 - ▶ **Direct TV.** Allows you view Direct TV channel options including Station ID, Genre, and Music Channel.
 - ▶ **Dish Network.** Allows you view Dish Network channel options including Station ID, Genre, Rating, and Music Channel.
 - ▶ **Cable TV.** Allows you to view Cable channel options, including Station ID, Genre, Rating, Music Channel.
 - ▶ **UHF/VHF.** Allows you to view the UHF channel options including Station ID, Genre, Rating, HDTV.
 - ▶ **AM/FM/XM.** Allows you to scan AM, FM, and XM stations.

**Media View — Media View Related Tasks
continued**

(left-side
selections
changer right-
side view)

- ▶ “Now that you have completed “Set up Media” refer to the System User Guide to test normal navigator device features.” on page 31
 - ▶ “Set up Media on DISC Changer” on page 17
 - ▶ “Set up Media for Broadcast Television Channels” on page 23
 - ▶ “Set up Media for Broadcast Stations” on page 25
 - ▶ “Create Playlist” on page 29
 - ▶ “Refresh Navigators” on page 31
-


Menu Bar

**Menus**

The Menu bar provides the following menus:

- ▶ **File menu** — Use to connect to the Director on your home network, refresh Navigator devices with new media information, and exit Composer Media Edition.
 - ▶ **Media menu** — Use to create new playlist. Also, use to clear, export, and import media lists. See “Media Menu” on page 13.
 - ▶ **Help menu** — Use to view on-line help and versioning information. See “Help Menu” on page 14.
-

File Menu



From the **File** menu, you can connect or disconnect from a Director, refresh Composer and Navigator devices, including Wireless Touch Screen, On-Screen, and Mini Touch Screen. You can also exit Composer.


File Menu

- ▶ **Connect to Director.** Connects you to a Director residing on the controller hardware. When you connect, project configuration information from the controller hardware is presented to the screen in Composer.
- ▶ **Disconnect from Director.** Disconnects you from a Director. It prompts you to back up your project before disconnecting you from the currently connected Director. This option is available when connected to a Director.
- ▶ **Refresh.** Refreshes the Composer Media Edition screen with the current information from Director.
- ▶ **Refresh Navigators.** Refreshes the Navigator devices with the latest information from Director. Some navigator devices include Wireless Mini Touch Screen, On-screen, Mini Touch Screen, and System Remote Control.
- ▶ **Exit.** Exits Composer. It prompts you to backup the project, prior to exiting the software and returning to the desktop.

File Menu Related Tasks:

- ▶ “Start Composer Media Edition Software” on page 4
- ▶ “Connect to Director on Local Network” on page 38
- ▶ “Refresh Navigators” on page 31
- ▶ “Exit Composer” on page 39

Media Menu



From the **Media** menu, you can create new playlists.

Also, you can use the **Media** menu to clear, export, and import media lists. *Media List* is the list of media information pertaining to the selected device, such as all DVDs with associated cover art, title, notes, etc. for each DVD in a DVD changer.

The media has either been scanned or manually added into the Media Database. After an item is added to the Media Database, the cover art and information about the media is viewable and selectable from any of the navigation devices, such as Mini Touch Screen, Wireless Touch Screen, On-Screen (viewable from TV monitor), etc.



TIP: It is recommended that you use the Export Media List feature so that you have a list of all your media saved to the hard drive of your PC.


Media Menu

- ▶ **Clear Media List.** Clears the media list of the highlighted device from the Media Database.
- ▶ **Import Media List.** Imports a media list from the PC to the controller hardware, such as Media Controller.
- ▶ **Export Media List.** Exports a media list for selected device from the controller hardware (such as Media Controller) to your PC.
- ▶ **Create Playlist.** Allows you to create a playlist of MP3 files. The playlist will be available from any navigator device, such as Wireless Touch Screen, On-screen, and Mini Touch Screen. You can create playlist of any MP3 files that reside on the controller hardware, such as Media Controller. You can add albums, remove songs, reorder songs, etc. If you remove songs from a playlist, it does not remove it from the Media Database.
- ▶ **Delete Playlist.** Allows you to remove a playlist.

Media Menu Related Tasks:

- ▶ “Clear Media List” on page 37
- ▶ “Import Media List” on page 39
- ▶ “Export Media List” on page 39
- ▶ “Create Playlist” on page 29

Help Menu



From the **Help** menu, you can access the on-line documentation version of this manual with index and search options.

You can also check for updates and check the version of your Composer software and Director component.

Help Menu

From the Help Menu, you have the following options:

- ▶ **Contents.** Displays the Content tab of the User Help.
- ▶ **Index.** Displays the Index tab of the User Help.
- ▶ **Check for Updates.** Takes you to the web update service allowing you to update Composer software and the associated drivers.
- ▶ **About Composer.** Displays the Composer, Director, and Media Manager version information.

Related Tasks:

- ▶ “Update Composer Media Edition from Help Menu” on page 40
 - ▶ “Search Topic” on page 40
 - ▶ “View Index” on page 41
-

Chapter 2 Set up Media and Playlists

To view and select the media from the Navigator devices, including Wireless Touch Screen, On-screen, Mini Touch Screen, and System Remote Control, you first need to add and scan the media to the controller hardware (such as Media Controller).

With the MP3 files you have added and scanned, you can create playlists of MP3 files saved to the controller hardware's hard drive or the external hard drive.



TIP: This product requires that your system is functioning correctly before using this software. For example, if a DISC Changer is not appearing on the left pane, there is not a DISC Changer in the system to add media to it. You will need to contact your authorized Control4 dealer to add a device not appearing to the Control4 system.

Please see your authorized Control4 dealer if the product does not work properly.

Topics covered in this chapter:

- ▶ “Set up Media on a Controller”
- ▶ “Set up Media on DISC Changer” on page 17
- ▶ “Set up Media for Broadcast Television Channels” on page 23
- ▶ “Set up Media for Broadcast Stations” on page 25
- ▶ “Create Playlist” on page 29
- ▶ “Refresh Navigators” on page 31

Set up Media on a Controller

When you set up media on a controller with a storage space for media, the controller has a built-in Digital Audio Player.


Digital Audio is the “cloud” in the controller that provides the digital audio streaming. Each source device that can provide an audio stream, whether it is a CD changer plugged into the analog inputs on a Control4 Speaker Point or a Control4 controller, such as a Media Controller, can provide audio to the Digital Audio servers. Each must have a connection to the Digital Audio Cloud. When configuring these connections under the **Connections** view, there is

Set up Media on a Controller

always an open connection to the Digital Audio Cloud for each Digital Audio Server or Digital Audio client. Therefore, you will potentially see many connections to the Digital Audio Cloud depending on the hardware configured in the project.

To add and scan available Digital Audio Player media by doing the following:


1. Within the controller pane (right pane), click **Add**.



TIP: If you get a dialog box that states you cannot add, make sure you have identified your Media Controller or controller hardware in the **Connections** view > **Network** tab.

2. Browse to directory of music files to add.

Once the files are added, the scan automatically starts. After a few moments the media is scanned and you will see a list of albums appear. You might see the On-screen navigator update during this process.



3. Refresh Navigator devices. See “Refresh Navigators” on page 31.


The media is now selectable for viewing within the Navigator devices, including Wireless Touch Screen, On-screen, Mini Touch Screen, and System Remote Control.

Set up Media on DISC Changer

When setting up a DISC Changer, you can add and scan media according to the options available on your DISC Changer. Adding and scanning populates the media information to the Media Database, which allows you to view the media from your Navigator devices, including Wireless Touch Screen, On-screen, Mini Touch Screen, and System Remote Control.

In the Media pane (left pane), when you highlight **DISC Changer**, if options are available on your DISC Changer, you will see following active buttons:

- ▶ **Scan** — Allows you to add and scan media located on your DISC Changer and add them to the Media Database (recommended if available).
- ▶ **Search** — Allows you to search for media titles located on your DISC Changer and add them to the Media Database.
- ▶ **New DVD or New CD** — Allows you to add new DVDs and CDs to the Media Database.



The following sections show how to add media to the Media Database using these options.

Set up Media on DISC Changer

To scan media on DISC Changer to Media Database:

1. Highlight **DISC Changer** in the **Media** pane (left pane).
2. In the **DISC Changer** pane (right pane), click **Scan**.

The scan results appear. After you Refresh Navigators you are ready to play music. See “Refresh Navigators” on page 31.



To search media on DISC Changer to add to Media Database:

1. Highlight **Media Controller** in the **Media** pane (left pane).
2. In the **DISC Changer** pane (right pane), click **Search**.

The search dialog appears.


3. Type the DVD name into the blank field.

Example: “A Beautiful Mind”

The possible DVD title matches from the web database appears in the **Search Results** window.

4. Use the scroll bar if necessary to find the appropriate DVD title.

5. Highlight the appropriate DVD title and drag it directly over the empty line item and highlight it.



Highlight the cover art and drag and drop it directly over to highlight the empty line item in the DVD pane. If you are adding DVDs for a multiple IR-controlled DISC Changer, you would add it in the same manner.

6. Click **Finished**.
7. Repeat these steps for the DVDs/CDs in the DISC Changer you want to add to the Media Database.
8. Refresh Navigator devices. See "Refresh Navigators" on page 31.

The media you have added is now selectable for viewing within the Navigator devices, including Wireless Touch Screen, On-screen, Mini Touch Screen, and System Remote Control.

Set up Media on DISC Changer

To add and search using New DVD or New CD options:

1. Highlight **DISC Changer** in the **Media** pane (left pane).
2. Highlight the **empty** field for the **New DVD** and **New CD** buttons to appear.
3. Click either **New DVD** or **New CD** as appropriate.




The **New Movie** or **New Album** dialog appears.

4. In the **Title** field, enter the DVD you want to play.

Example: A Beautiful Mind

5. Click **Search**.




6. When the **Search** dialog appears, use the scroll bar if necessary to find the appropriate cover art and click to highlight it.

You can change the search criteria and search again if necessary. The possible matches from the web database appear in the **Search Results** window.

7. Click **Next**.

You can choose which information to import and edit any associated information before adding to the Media Database.



From this screen, you can customize your view, rename fields, deselect check boxes, etc.

8. Click **Finished**.

9. Click **OK**.




10. Refresh Navigator devices. See “Refresh Navigators” on page 31.

This particular DVD is now selectable for viewing within the Navigator devices, including Wireless Touch Screen, On-screen, Mini Touch Screen, and System Remote Control.

Autoscan Media Within Composer

This is a new documentation topic. The benefits of running a DISC Changer with bi-directional communications (RS-232), such as Sony CX777ES, is that you can scan your DVDs/CDs stored in the disc changer to identify, index, and automatically apply cover art information.

You can configure your system within Composer or Composer Media Edition to automatically scan media or to manually scan media when the **Scan** button is selected within Composer or Composer Media Edition for the associated DISC changer. The default is to scan media manually.



When the **Auto Scan Enabled** option is selected from the device properties page, the automatic scan of disc(s) is available only when you add a new disc to an empty slot or a disc is removed. Whenever a disc is added to an empty slot or a disc is removed, the DISC Changer will automatically recognize the change. The Navigator devices will automatically update with the change. The DISC Changer recognizes the changes in its slot when its door closes to perform the automatic scan. The Autoscan feature does not detect when a disc is replaced or swapped.



NOTE: If a DVD/CD is scanned and the media is not recognized, it will be titled as "unknown." You can edit the information about the DVD/CD and manually provide this information from either Composer or the Navigation devices. If this DVD/CD is then changed to a different slot, the system will apply this same information.

Related Topics:


"Edit Media Information within Composer" on page 31

"See also Navigation device user documentation for editing media cover art using one of the Navigation devices."

Autoscan Added Media

To autoscan added media:

1. From the Project Tree, click the **Sony CX 777ES DISC Changer** added to the project.
The device properties page appears.
2. Ensure that a check is in the **Auto Scan Enabled** box.



3. Open the DISC changer drive and change the existing DVD/CD.
4. The autoscan begins automatically when the DISC Changer door closes and the information for the added DVD/CD is automatically available from the navigation devices.


Set up Media for Broadcast Television Channels

Set up Media for Broadcast Television Channels

1. Highlight **UHF/VHF** or other broadcast media type.
2. Click **Search**.
3. When the dialog appears, note that your zip code appears automatically in the field.
4. Click **Search** and use the pull-down menu to select **Local Broadcast Listings**.
The available channels are populated to the Search Results.
5. Click the boxes to select the desired channels that you want to appear on the Navigator devices, including Wireless Touch Screen, On-screen, Mini Touch Screen, and System Remote Control.

Set up Media for Broadcast Television Channels

6. Click **OK**.



The selected stations populate in the UHF/VHF pane.




7. Refresh Navigator devices. See “Refresh Navigators” on page 31.

The media is now selectable for viewing within the Navigator devices, including Wireless Touch Screen, On-screen, Mini Touch Screen, and System Remote Control.


Set up Media for Broadcast Stations

Set up Media for Broadcast Radio Stations:

1. Click **Search**.
2. When the dialog appears, note that your zip code appears automatically in the field.
3. Click **Search** and use the pull-down menu to select **AM Broadcast Stations or FM Broadcast Stations**.
The available stations are populated to the **Search Results** window.
4. Click the boxes to select desired stations that you want to appear on the Navigator devices, including Wireless Touch Screen, On-screen, Mini Touch Screen, and System Remote Control.
5. Click **OK**.



The selected stations populate in the **FM Radio** pane.



6. Refresh Navigator devices. See “Refresh Navigators” on page 31.
7. Repeat steps 1-7 for each radio (AM, FM, XM) you want to set up. Each of these must be set up separately.

The media is now selectable for viewing within the Navigator devices, including Wireless Touch Screen, On-screen, Mini Touch Screen, and System Remote Control.

Use External Storage Devices

You can access digital music from an external storage device on your Control4 system. External storage devices include USB flash drives or USB external hard drives or a PC's drive located on the home network.

You need to set up according to the external storage device and networked file storage as described in this section. External storage devices must have media stored in unprotected MP3 format.



NOTE: When you remove the external drive (network, USB, etc.), the music is no longer available. In order to access the music again, return the external storage device and from the **File** menu, select **Refresh Navigators**.

To attach and scan external storage devices using a USB connection:


1. If you need to power on the external storage device, turn it on.
2. Use the documentation provided with your controller hardware to attach the external hard drive using the USB port.

3. Once you physically connect the external storage device, you need to scan the music residing on the external device connected to the controller hardware (such as Media Controller) to make it available on the Control4 system.
4. Highlight the controller to which the external device is connected.
5. Click **Scan**.



You can add media from the external storage device when connected to the Media Controller. However, it is recommended that you connect your external drive directly to the PC where you want to copy media.

When scanning, the media appears as it is located on the controller hardware.



To access and scan network storage devices:

1. Use the documentation provided with your operating system to create a shared network drive.

Example: Using Windows XP to make a local C:/ Drive directory available on the network, right-click the folder and select **Sharing and Security**. Select the **Share this folder** button.
2. Configure the username, password, and workgroup (or domain) for the network file share.

This information varies between types, contact your system administrator if you need help with this information.
3. Highlight the **Network File Storage** object (left pane).

4. Click **Add** or **Scan**.



Add an Audio or Audio/Video Switch to Control4 System

To highlight a few Audio/Video Switch products, the following audio or audio/video switch drivers are now available for use in the Control4 system:

- Control4 Audio Switch
- Anthem MCA 50 (Relay)
- B&K AV2600 (Relay)
- Knox RS16x15 HB
- Knox RS16x15 HB AO
- Knox RS16x15 HB VO
- Knox RS4x4 HB
- Knox RS8x8 HB
- Knox MediaFlex16
- Marantz MM-9000 (IR)
- McIntosh MC2102 (Relay)
- Meridan 558.2 (Relay)
- Parasound HCA-1500A (Relay)
- Pioneer PRO-R05U (IR)
- Primare Systems A30.3 MKII (Relay)
- Rotel RB-993 (Relay)
- Sony TA-N220 (IR)

As more are continually added, you can access the AV switch drivers from within the **System Design** view in the **Items** pane, select **Search** tab > **Device Type: A/V Switch** or **Audio Switch** > **Manufacturer: All Manufacturers**. Use the Driver Wizard for additional support for your audio or audio video switch.

To add an Audio or Audio/Video Switch:

1. Set up the audio or audio/video switch and any associated hardware.
2. Add the audio or audio/video switch to your project from within the System Design view, under the Items pane, select the **Search** tab > **Device Type: Audio Switch** or **A/V Switch** > **Manufacturer: All manufacturers**.

Example: To add the applicable Knox A/V switch (RS-232) driver, within the **System Design** view, under the **Items** pane, select the **Search** tab > **Device Type: A/V Switch** > **Manufacturer: All manufacturers**.

3. When the A/V Switch object is added to the project tree, highlight the object to view the device properties for that object to make configuration changes if applicable.


Example: The Knox A/V Switch has no properties to modify, but other switches have properties, such as the Control4 Audio Switch.

4. Make any necessary network or control/AV connections as necessary for your configuration.
5. Modify any room connection bindings as needed for your configuration.

Create Playlist

To create playlist:

1. From the **Media** menu, select **New Playlist**.



2. A **New** playlist will appear that you can rename immediately or later you can right-click and select **Edit** to change the name.

Example: Change **New** to **Frank's Playlist**.


3. Ensure that you have scanned your media in the **Digital Audio** player.

The Playlists are designed exclusively for streaming media within Digital Audio. Playlists are not intended to include CDs/DVDs or broadcast channels or stations.

4. Highlight **Media Controller**.

Create Playlist

5. Drag and drop any albums or individual songs you want to add to the playlist to Frank's Playlist.



6. After you have added the albums, highlight the playlist to delete songs you do not want in your playlist by right-clicking the song and selecting **Delete**. You can select more than one by holding down the shift key.



TIP: To remove individual song, right-click **Delete**. To remove multiple songs, press shift and highlight items, then right click **Delete**.


Now you are able to edit and play your playlist using the Navigator devices, including Wireless Touch Screen, On-screen, Mini Touch Screen, and System Remote Control.

Refresh Navigators

1. In case your Navigators did not automatically refresh, choose **File > Refresh Navigators**.



TIP: New media will show up automatically in the Navigators unless you have a device that is disconnected or has changed locations..



2. Now that you have completed “Set up Media” refer to the *System User Guide* to test normal navigator device features.

Edit Media Information within Composer


You can edit the media information for “Unknown” DVDs or CDs using the *Composer Professional* or *Media Editions*. See the instructions that follow. You can also edit the media information within the Navigator devices, such as On-Screen Navigator, Touch Screen, or Mini Touch Screen.

Edit CD Information within Composer


To edit a CDs information within Composer:

3. Double-click the device you would like to edit a CD on, such as **CD, DISC Changer, Media Controller** or **Digital Audio**.


4. Click the **Edit** button or double-click the album under **Album Title**.




5. To edit and enter any changes, click in the boxes under **Name**, **Artist**, **Label** or **Genre** under the **Album** tab. Under **Tracks** and **Notes** tabs, view and edit **Track Titles** and **Notes**. When finished click **OK**. (Click **Cancel** to exit screen.)



- Click one of the **Search** buttons beside **Name** or **Artist** to search the database for similar entries.



- To select a search result, select the album **Title** and double-click or click **Next**. At the next screen you can view and edit the information of the album, including **Name**, **Artist/Composer**, **Label**, **Genre**, **Year**, **Art**, and **Notes**.



Edit Media Information within Composer

8. Make changes as desired and click **Finished**. If you would like to return to previous screens to make changes, click **Back**.

Search

Name
4 - Four (Hybrid SACD)

Artist/Composer
Turtle Island String Quartet

Label
Telarc

Genre
NewAge

Year
2005

Notes

Art

Current Track Number and Title

New Track Number and Title

1. Around And Around
01 Around And Around.mp3

2. Confessin' The Blues
02 Confessin' The Blues.mp3

3. Empty Heart
03 Empty Heart.mp3

4. Time Is On My Side
04 Time Is On My Side.mp3

5. Good Times Bad Times
05 Good Times Bad Times.mp3


© 2005 All Media Guide, LLC
Content provided by AllMusic Guide®, a trademark of All Media Guide, LLC

< Back Finished Cancel


Edit DVD Information Within Composer

To edit a DVD's information within Composer:

1. Choose a movie under **DISC Changer** or **DVD**.
2. Click the Edit button or double-click the title under **Discs**.



3. Under the **Movie** tab, edit the **Title**, **Director**, **Studio**, **Genre**, **Run Time**, **Release date** and **Rating** as desired on this screen under the **Movie** tab. Under the **Cast and Synopsis** tab click in **Cast** and **Synopsis** fields to make desired changes.



Edit Media Information within Composer

4. Click **Search** under the **Movie** tab to search the database for other DVDs.
5. Double-click the desired DVD and edit as desired according to the steps above.
6. When you are done with your changes, click **Finished**.

The screenshot shows a 'Search' dialog box with the following fields and values:

- Title:** 20,000 Leagues Under the Sea
- Director:** Richard Fleischer
- Studio:** Disney DVD
- Genre:** Adventure
- Run Time:** 127
- Released:** 1954
- Rating:** G

The **Cast** list includes: Kirk Douglas; James Mason; Paul Lukas; Peter Lorne; Robert J. Wilke; Catelein Young; Percy Helton; Ted Cooper; Edward Mar; Fred Gohm.

The **Synopsis** text reads: "This 1954 Disney version of Jules Verne's 20,000 Leagues Under the Sea represented the studio's costliest and most elaborate American-filmed effort to date. Kirk Douglas plays a trouble-shooting 19th century reefer, trying to discover why so many whaling ships have been disappearing of late. Teaming with scientist Paul Lukas and diver Peter Lorne, Douglas sets sail to investigate—and is promptly captured by the megalomaniac Captain Nemo (James Mason), who slips a lavish, scientifically advanced submarine. The film's special effects, including a giant squid, were impressive enough in 1954 to win an Academy Award. Hal Erickson, All Movie Guide." Below the synopsis is the copyright notice: "[C] 2005 All Media Guide, LLC. Content provided by All Music Guide(TM), a trademark of All Media Guide, LLC." At the bottom right, the **Finished** button is circled in red.

Chapter **3** Other Composer Tasks

This chapter provides steps for performing tasks using Composer.

Clear Media List

To clear media list:

1. Highlight the device that you want to clear the Media List.

Example: Digital Audio

2. From the **Media** menu, select **Clear Media List**.

This removes the information including the title art and information from the Media Database. This option does not remove the actual media files.

Connect to Director on Local Network

To connect to a Director on your home network:

1. Start Composer:

- ▷ From the desktop, double-click the **Composer** icon.




- ▷ Or go to the Composer Startup screen that is displayed, choose **Director on Local Network**.



NOTE: Within Composer, to connect to a Director on your home network, from the **File** menu, select **Connect to Director**.

2. From the Director dialog that appears, choose the Director's address of the Media Controller you are setting up and choose **Connect**.



Exit Composer

To exit Composer:

- ▶ From the Composer Startup screen, choose **Exit Composer**
- ▶ From menu bar, choose **File > Exit**.

Export Media List

To export the Media List:

1. Highlight the device that you want to export the Media List.

Example: Digital Audio

2. From the **Media** menu, select **Export Media List**.

This saves a copy of the file that contains all the title art and information from the Media Database to your PC. This option does move the actual media files.

Import Media List

To import the Media List from the PC to Media Database:

1. Highlight the device that you want to import the Media List.

Example: Digital Audio

2. From the **Media** menu, select **Import Media List**.

This saves a copy of the file that contains all the title art and information from your PC to the Media Database. This option does not move the actual media files.

Search Topic

To search documentation:

1. Select **Help > Search** tab.
2. Enter a topic you want to find.
3. Press **Enter**.
4. Choose from the available entries.

Update Composer Media Edition from Help Menu

To update Composer from the Help menu:

1. From the Help menu, select **Check for Updates**.
2. Follow the online instructions to complete the update.

Update Composer Media Edition from Windows Start Menu

To update Composer from Windows Start Menu:

1. Select **Start > All Programs > Control4 > Composer > Update Composer**.
2. Follow the online instructions to complete the update.

Update Composer Media Edition by Running Installation

To update Composer from the installation:

1. Run the installation.
2. Follow the online instructions to complete the update.

View Index

To access documentation index:

1. Select **Help > Index** tab.
2. View the available topics and subtopics.
3. Choose from the available entries by double-clicking an entry to view the topic or a list of subtopics.

[View Index](#)

Index

A

- A/V Switch 28
- Add an Audio or Audio/Video Switch to Control4 System 28
- Add and search using New DVD or New CD options 20
- Auto Scan Enabled 23
- Autoscan Added Media 23
- Autoscan Media Within Composer 22
- A-Z Tasks
 - Add an Audio or Audio/Video Switch to Control4 System 28
 - Add and search using New DVD or New CD options 20
 - Autoscan Media Within Composer 22
 - Channels 23
 - Clear Media List 37
 - Connect to a Local Director 38
 - Connect to Director on Local Network 38
 - Create Playlist 29
 - Edit CD Information within Composer 31
 - Edit DVD Information Within Composer 35
 - Edit Media Information within Composer 31
 - Exit Composer 39
 - Export Media List 39
 - Import Media List 39
 - Install Composer Media Edition Software 3
 - Launch Composer Media Edition Software 4
 - Refresh Navigators 31
 - Scan media on DISC Changer to Media Database 18
 - Search media on DISC Changer to add to Media Database 18
 - Search Topic 40
 - Set up Media for Broadcast Stations 25
 - Set up Media on Digital Audio Player 15
 - Set up Media on DISC Changer 17
 - Software and Network Requirements 2
 - Update Composer Media Edition by Running Installation 40
 - Update Composer Media Edition from Help Menu 40
 - Update Composer Media Edition from Windows Start Menu 40
 - Use External Storage Devices 26
 - View Index 41

B

- Broadcast Stations Set up 25
- Broadcast Television Channels Set up 23

C

- Clear Media List 37
- Composer 7
- Composer Media Edition Startup 8
- Composer software, defined 1
- Composer Startup Screen 8
- Connect to a Local Director 38
- Connect to Director on Local Network 38
- Create Playlist 29

D

- Directors dialog 9
- DVD Information 35

E

- Edit CD Information within Composer 31
- Edit DVD Information Within Composer 35
- Edit Media Information within Composer 31
- Exit Composer 39
- Export Media List 39
- External Storage Device 26

F

- File Menu 12
- File menu
 - definition 11
 - description 12

G

- Get Started 1

H

- Help Menu 14
- Help menu
 - definition 11
 - description 14

I

- Import Media List 39

Install Composer Media Edition Software 3
Interface

Set up Media on Digital Audio Player 15

interface

Composer Startup Screen
description 8

Composer, main interface 7

Directors dialog
description 9

File menu
definition 11

File menu, description 12

Help menu
definition 11

Help menu, description 14

Media menu
definition 11

Media menu, description 13

Media view
description 10

Menu bar
description 11

L

Launch Composer Media Edition Software 4

Local Network 38

M

Media
setup tutorial 15

Media Edition Software 4

Media List 37

Media Menu 13

Media menu
definition 11
description 13

Media View 10

Media view
description 10

Menu Bar 11

Menu bar
description 11

N

Navigator Refresh 31

O

Other Composer Tasks 37

P

Playlist Creation 29

R

Refresh Navigators 31

S

Scan media on DISC Changer to Media Database 18

Search media on DISC Changer to add to Media
Database 18

Search Topic 40

Set up Media for Broadcast Stations 25

Set up Media for Broadcast Television Channels 23

Set up Media on Digital Audio Player 15

Set up Media on DISC Changer
description 17

New DVD or CD 17

Scan 17

Search 17

Software and Network Requirements 2

T

tutorials

Media Setup Tutorial 15

Navigator User Interface Setup Tutorial 15

U

Update Composer Media Edition by Running Installation
7, 40

Update Composer Media Edition from Help Menu 40

Update Composer Media Edition from Windows Start
Menu 40

Use External Storage Devices 26

User interface
setup tutorial 15

V

Version 1.2.1

Highlighted

Autoscan Media Within Composer 22

Version 1.2.3 28

View Index 41